SAMSUNG

Operating Instructions and Cooking Guide

SPEED COOK OVEN

CQ4260

Owner's Manual

Contents

Using This Manual 4
Important Safety Instructions 4
Precautions to Avoid Possible Exposure to Excessive Microwave 4
Installing Your Microwave Oven 8
Setting the Clock 9
Oven Features 10
Accessories. 11
Control Panel 12
Types of Heating. 13
Using Oven Mode 14
Setting Oven Mode 14
Dual Convection Setting 16
Convection + Top Heat Setting 17
Conventional Heat Setting 18
Grill & Rotisserie Setting 19
Grill & Rotisserie Setting 20
Convection + Bottom Heat Setting 21
Setting Cook Time. 22
Setting End Time. 23
Cooking Time Reservation Function 24
Using Speed Menu Mode 25
Setting Speed Menu Mode 25
Guide to Auto Speed Menu Settings 26
Using Speed Defrost Mode. 28
Setting Speed Defrost Mode 28
Guide to Auto Speed Defrost Settings 29
How a Microwave Oven Works 30
Using Microwave Mode. 31
Setting Microwave Mode. 31
Guide to Microwave Power Levels 32
Microwave Cookware Guide 33
Microwave Cooking Guide 35
Switching Off the Beeper 41
Child Safety Lock 42
Using the Steam Clean Feature 43
Cleaning Your Microwave Oven 44
Storing and Repairing Your Microwave Oven 44
Troubleshooting 45
Error Codes. 46
Technical Specifications 47

EN

Using This Manual

Thank you for purchasing a SAMSUNG speed cook oven.

Your Owner's Manual contains important safety instructions and essential information on using and caring for your new speed cook oven.

Before using your oven, please read all the information in this manual and keep it for future reference.

A handy quick look-up guide explaining basic cooking operations is provided inside the front cover for your convenience.

Important Safety Instructions

PRECAUTIONS TO AVOID POSSIBLE EXPOSURE TO EXCESSIVE MICROWAVE

Failure to observe the following safety precautions may result in harmful exposure to microwave energy.

(a) Under no circumstances should any attempt be made to operate the oven with the door open or to tamper with the safety interlocks (door latches) or to insert anything into the safety interlock holes.

(b) Do not place any object between the oven door and front face, or allow food or cleaner residues to accumulate on sealing surfaces. Ensure that the door and door sealing surfaces are kept clean by wiping after use with first a damp cloth and finally with a soft dry cloth.

(c) Do not operate the oven if it is damaged until it has been repaired by a qualified microwave service technician trained by the manufacturer. It is particularly important that the oven door closes properly and that there is no damage to the:

(1) door, door seals and sealing surfaces,
(2) door hinges (broken or loose), or
(3) power cable.

(d) The oven should not be adjusted or repaired by anyone other than a properly qualified microwave service technician trained by the manufacturer.

Important Safety Instructions (Continued)

EN

Read carefully and keep for future reference.

Before cooking food or liquids in your oven, please check that the following safety precautions are taken.

1. **DO NOT** use any metallic cookware when using microwave function:
   - Metallic containers
   - Dinnerware with gold or silver trimmings
   - Skewers, forks, etc.

   Reason Electric arcing or sparking may occur and may damage the oven.

2. **DO NOT** heat:
   - Airtight or vacuum-sealed bottles, jars, containers. Ex) Baby food jars
   - Airtight food. Ex) Eggs, nuts in shells, tomatoes

   Reason The increase in pressure may cause them to explode.
   Tip Remove lids and pierce skins, bags, etc.

3. **DO NOT** operate the microwave function when it is empty.
   Reason The oven walls may be damaged.
   Tip Leave a glass of water inside the oven at all times. The water will absorb the microwaves if you accidentally set the oven going when it is empty.

4. **DO NOT** cover the rear ventilation slots with cloths or paper.
   Reason The cloths or paper may catch fire as hot air is evacuated from the oven.

5. **ALWAYS** use oven gloves when removing a dish from the oven.
   Reason Some dishes absorb microwaves and heat is always transferred from the food to the dish. The dishes are therefore hot.

6. **DO NOT** touch heating elements or interior oven walls.
   Reason These walls may be hot enough to burn skin even after cooking is finished, oven though they do not appear to be so. Keep away from hot spot. Do not allow inflammable materials to come into contact with any interior area of the oven. Let the oven cool down first.

7. To reduce the risk of fire in the oven cavity
   - Do not store flammable materials in the oven
   - Remove wire twist ties from paper or plastic bags
   - Do not use your microwave oven to dry newspapers
   - If smoke is observed, keep the oven door closed and switch off or disconnect the oven from the power supply.

Important Safety Instructions (Continued)

8. Take particular care when heating liquids and baby foods using microwaves function.
- ALWAYS allow a standing time of at least 20 seconds after the oven has been switched off to allow the temperature to equalize.
- Stir during heating if necessary and ALWAYS stir after heating.



- To prevent eruptive boiling and possible scalding, you should stir before, during, and after heating.
- In the event of scalding, follow these FIRST AID instructions :
  * Immerse hand in cold water for at least 10 minutes.
  * Cover with clean, dry dressing.
  * Do not apply any creams, oils or lotions.
- **NEVER** fill the container to the top and choose a container that is wider at the top than at the bottom to prevent the liquid from boiling over. Bottles with narrow neck may also explode if overheated.
- **ALWAYS** check the temperature of baby food or milk before giving it to the baby.
- **NEVER** heat a baby's bottle with the teat on, as the bottle may explode if overheated.
- During microwave heating of beverages, there is the possibility of delayed eruptive boiling,therefore care has to be taken when handling the container.

9. Be careful not to damage the power cable.
- Do not immerse power cable or plug in water and keep power cable away from heated surfaces.
- Do not operate this appliance if it has a damaged power cable or plug.

10. Stand at arm's length from the oven when opening the door.
Reason The hot air or steam released may cause scalding.

11. Keep the inside of the oven clean.
- Clean the inside of the oven right after each use with a mild detergent solution, but let the microwave oven cool down before cleaning in order to avoid injury.

Reason Food particles or spattered oils stuck to oven walls or floor can cause damage to the ceramic finish and reduce the efficiency of the oven.

12. "Clicking" sound might be noticed while operating, especially in defrosting mode.
Reason When the power output is changing electrically, you may hear that sound. This is normal.

13. If the microwave mode is operating without any load, the power will cut off automatically for safety. After standing for over 30 min, you can operate the oven normally.

- Do not worry if the oven continues to work after cooking has finished.

Reason This product is designed to run the cooling fan for 5 minutes after the cooking has finished to cool down internal electronic parts. When cooking has finished, the oven will beep and flash “0” four times. The oven will then beep one time per minute.

IMPORTANT SAFETY INSTRUCTIONS

During cooking, you should look into the oven from time to time when food is being heated or cooked in disposable containers made of plastic, paper or other combustible materials.

IMPORTANT

Young children or infirm persons should **NEVER** be allowed to use or play with the microwave oven. Nor should they be left unattended near the microwave oven when it is in use. Items of interest to children should not be stored or hidden just above the oven.

WARNING

If the door or door seals are damaged, the oven must not be operated until it has been repaired by a competent person.

WARNING

It is hazardous for anyone other than a competent person to carry out any service or repair operation which involves the removal of a cover which gives protection against exposure to microwave energy.

WARNING

Liquids and other foods must not be heated in sealed containers since they are liable to explode.

WARNING

Only allow children to use the oven without supervision when adequate instructions have been given so that the child is able to use the oven in a safe way and understands the hazards of improper use.

WARNING

When heating food in plastic or paper containers, keep an eye on the oven due to the possibility of ignition;

WARNING

Ensure that the appliance is switched off before replacing the lamp to avoid the possibility of electric shock.

Please recycle or dispose of the packaging material for this product in an environmentally responsible manner.

Please contact your local authorities in regard to the enviromentally safe disposal of this product.

Installing Your Microwave Oven

EN

This microwave oven can be placed almost anywhere (kitchen work surface or shelf, movable trolley, table).



When you install your oven, make sure there is adequate ventilation for your oven by leaving at least 10 cm (4 inches) of space behind, and on the sides of the oven and 20 cm (8 inches) of space above the oven and 85 cm (33 inches) of the floor.



Remove all packing materials inside the oven. Install the roller ring and turntable. Check that the turntable rotates freely.

This microwave oven has to be positioned so that plug is accessible.

Note

- Never block the air vents as the oven may overheat and automatically switch itself off. It will remain inoperable until it has cooled sufficiently.
- For your personal safety, plug the cable into a 3-pin, 230 Volt, 50Hz, AC earthed socket. If the power cable of this appliance is damaged, it must be replaced by the manufacturer or its service agent or a similarly qualified person in order to avoid a hazard.
- Do not install the microwave oven in hot or damp surroundings like next to a traditional oven or radiator. The power supply specifications of the oven must be respected and any extension cable used must be of the same standard as the power cable supplied with the oven. Wipe the interior and the door seal with a damp cloth before using your microwave oven for the first time.

Setting the Clock

EN

When the appliance is first plugged in, the DISPLAY lights up. After three seconds, the Clock symbol and "12:00" blink on the DISPLAY.

Setting the Clock



1 Press **CLOCK** . The "12" starts blinking.



2 Turn **MULTI-FUNCTION SELECTOR** to set hour.



3 Press **CLOCK** again. The "00" starts blinking.



4 Turn **MULTI-FUNCTION SELECTOR** to set minute.



5 Press **CLOCK** again. The clock sets by itself within 5 seconds.

Oven Features

EN



Note

- Shelf levels are numbered from the bottom up.
- The levels 4 and 5 are mainly used for grill function.
- The microwave level is mainly used for microwave function.
- Please refer to Cooking Guides provided throughout this booklet to determine appropriate shelf level for your dishes.

Accessories

EN

The following accessories are provided with your microwave oven:



1 Ceramic Tray
(Useful for Microwave Mode)



2 Two Baking Trays
(DO NOT use for Microwave Mode.)



3 Grill Insert for Ceramic Tray
(Useful for Speed Menu and Grill Mode)



4 Oven Rack
(DO NOT use for Microwave Mode.)



5 Rotisserie
(Please apply olive oil or vegetable oil to rotating parts of each component for better rotation before using a rotisserie for the first time)

Note

Please refer to Cooking Guides provided throughout this booklet to determine appropriate accessory for your dishes.

Control Panel

EN



1. OFF
2. OVEN MODE
3. SPEED MENU MODE
4. SPEED DEFROST MODE
5. MICROWAVE MODE
6. MODE SELECTOR
7. DISPLAY
8. STEAM CLEAN
9. CLOCK
10. COOK TIME
11. END TIME
12. TEMPERATURE
13. POWER LEVEL / ENTER
14. MULTI-FUNCTION SELECTOR
15. STOP / CANCEL
16. START

Using Pop Up Dials

Note

The **MODE SELECTOR** (6) and **MULTI-FUNCTION SELECTOR** (14) are pop up dials. Simply press and turn to desired setting.

Types of Heating

EN

The following chart summarizes the various heating modes and settings available on your oven. Use the Cooking Guides in the pages that follow to determine the appropriate mode and setting for all your recipes.

OVEN MODE

	Dual Convection Setting Food is heated by hot air from the left and right sides of the oven. This setting provides uniform heating and is ideal for baking.
	Convection + Top Heat Setting Hot air and top heating element combine, making this setting ideal for crisping and browning. Especially recommended for meats.
	**Conventional Heat Setting** Heat comes from top and bottom heating elements. This setting is suitable for baking and roasting.
	**Grill Setting & Rotisserie** Food is heated by the top heating element. The rotisserie motor is activated during grilling, to enable the use of the rotisserie. This function can also be used without using the rotisserie.
	Convection + Bottom Heat Setting Hot air and the bottom heating element combine so food can be crisped and browned.

SPEED MENU MODE

	Choose from twelve pre-programmed speed menu settings to conveniently cook, roast or bake your favourite foods. Cooking time and power level are automatically set. Simply select the programme and weight to start cooking.

SPEED DEFROST MODE

	Choose from five pre-programmed speed defrost settings for defrosting. Defrosting time and power level are automatically set. Simply select the programme and weight to start defrosting.

MICROWAVE MODE

	Microwave energy is used to cook and defrost foods. It provides fast efficient cooking without changing the colour or form of food. Power level and cooking time are manually set to suit various dishes.

Using Oven Mode

EN

Five settings are available under this mode. Check Cooking Guides on pages 14 - 21 to determine appropriate setting.

Setting Oven Mode



1 Turn **MODE SELECTOR** Dial to oven mode position.



2 Turn **MULTI-FUNCTION SELECTOR** Dial to desired oven mode. The oven mode and recommended temperature will be displayed .

	Dual Convection	180°C
	Convection + Top Heat	180°C
	Conventional Heat	200°C
	Grill & Rotisserie	220°C
	Convection + Bottom Heat	180°C

Note

The convection heater and grill heater switch on and off constantly to regulate the temperature.

3 To change temperature, press **TEMPERATURE** and turn **MULTI-FUNCTION SELECTOR** to set desired temperature.



4 To set cooking time, press **COOK TIME** and turn **MULTI-FUNCTION SELECTOR** to set desired cooking time.



5 Press **START**.

► The **TEMPERATURE** indicator on display will be lit and the indicator will blink after the temperature is reached.

Note

1) During cooking, **COOK TIME** and **TEMPERATURE** are available to change the setting.
2) In Oven Mode settings, the convection heater and top and bottom heating elements switch off and on throughout cooking to regulate the temperature.
3) During cooking, the inside temperature is displayed by pressing **TEMPERATURE** and **POWER LEVEL / ENTER** at the same time.

Important

When using Oven Mode, be sure glass baking dishes are suitable for 40 - 250 °C cooking temperatures.

EN

Dual Convection ( ) Setting

Food is heated by hot air from the left and right sides of the oven. This setting provides uniform heating and is ideal for baking.



When you cook on two baking trays at the same time, place the trays on level 2, and level 4.

*Please ensure that glass baking dishes are suitable for 40 ~ 250 °C cooking temperatures.

Cooking Guide

Use temperatures and times in this table as guidelines for baking.
We recommend to preheat the oven with dual convection mode.

Food Item	Shelf Level	Temperature (°C)	Accessory	Time (h)
Hazelnut Cake Square Mould	2	160 - 170	Oven rack	1:00 - 1:10
Lemon Cake Ring-Shaped or Bowl Mould	2	150 - 160	Oven rack	0:50 - 1:00
Sponge Cake	3	150 - 160	Oven rack	0:35 - 0:45
Fruit Flan Base	3	150 - 170	Oven rack	0:25 - 0:35
Flat Streusel Fruit Cake (Yeast Dough)	3	150 - 170	Baking tray	0:30 - 0:40
Croissants	3	170 - 180	Baking tray	0:10 - 0:15
Bread Rolls	2	180 - 190	Baking tray	0:10 - 0:15
Cookies	3 / 4	160 - 180	Two baking trays	0:10 - 0:20

Note

Preheating is recommended.

EN

Convection + Top Heat ( ) Setting

Hot air and top heating element combine, making this setting ideal for crisping and browning. This setting is especially recommended for cooking meats.



When cooking meat, place on rack on Level 3 and set baking tray on Level 1 to catch drippings.

*Please ensure that glass baking dishes are suitable for 40 ~ 250 °C cooking temperatures.

Cooking Guide

Use temperatures and times in this table as guidelines for roasting.
We recommend to preheat the oven using Convection + Top Heat mode.
Put meat on oven rack, follow shelf level advice in the table and use baking tray as oil pan on level 1.

Food Item	Shelf Level	Temperature (°C)	Accessory	Time (h)
Beef Roast Beef / 1 kg Medium	3 / 1	170 - 190	Oven rack / Baking tray	1:00 - 1:30
Pork Shoulder Joint / Roll 1 kg	3 / 1	180 - 200	Oven rack / Baking tray	1:30 - 2:00
Lamb Roast Lamb / Leg of Lamb 0.8 kg	2 / 1	190 - 210	Oven rack / Baking tray	0:50 - 1:20
Chicken Whole Chicken 1 kg	3 / 1	170 - 190	Oven rack / Baking tray	0:50 - 1:10
Fish Whole Trouts 2 pcs / 0.5 kg	4 / 1	170 - 180	Oven rack / Baking tray	0:30 - 0:40
Duck Breast 0.3 kg	4 / 1	180 - 200	Oven rack / Baking tray	0:25 - 0:35

Note

Preheating is recommended.

EN

Conventional Heat ( ) Setting

Heat comes from top and bottom heating elements. This setting is suitable for baking and roasting.



Baking tray or oven rack is usually placed on Level 3.

*Please ensure that glass baking dishes are suitable for 40 ~ 250 °C cooking temperatures.

Cooking Guide

Use temperatures and times in this table as guidelines for baking. We recommend to preheat the oven with Conventional Heat mode.

Food Item	Shelf Level	Temperature (°C)	Accessory	Time (h)
Lasagne	3	200 - 220	Oven rack	0:25 - 00:35
Vegetables Gratin	3	180 - 200	Oven rack	0:20 - 00:30
Potato Gratin	3	180 - 200	Oven rack	0:25 - 00:35
Frozen Pizza Baguettes	3	160 - 180	Baking tray	0:10 - 00:15
Oven Chips	3	200 - 220	Baking tray	0:15 - 00:20
Marble Cake	3	180 - 200	Oven rack	0:50 - 1:10
Muffins	3	180 - 200	Oven rack	0:10 - 00:15
Cookies	4	180 - 200	Baking tray	0:08 - 00:15

Note

Preheating is recommended.

EN

Grill & Rotisserie ( ) Setting

Food is heated by the top heating elements.



For grilling, ceramic tray with grill insert is usually placed on Level 4.

*Please ensure that glass baking dishes are suitable for 40 ~ 250 °C cooking temperatures.

Cooking Guide

Use temperatures and times in this table as guidelines for grilling. Set 220 °C grill temperature, preheat for 3 minutes.

Food Item	Shelf Level	Time (Min) 1st side	Time (Min) 2nd side	Accessory
Kebab Spits	4	8 - 10	6 - 8	Grill insert with ceramic tray
Pork Steaks	4	7 - 9	5 - 7	Grill insert with ceramic tray
Sausages	4	4 - 6	3 - 5	Baking tray
Chicken Pieces	4	10 - 15	8 - 10	Grill insert with ceramic tray
Salmon Steaks	4	8 - 12	6 - 10	Grill insert with ceramic tray
Sliced Vegetables	5	5 - 7	3 - 5	Baking tray
Toast	5	2 - 3	1 - 2	Oven rack
Cheese Toasts	5	4 - 5	-	Oven rack

Note

Recommended temperature for grilling is 220 °C.
Preheating for three minutes is recommended.

EN

Grill & Rotisserie ( ) Setting

Food is heated by the top heating elements.



For grilling with the rotisserie, the rotisserie holder is placed on level 5. The rotisserie is placed in the holder, the central spit must be inserted in the slot in the back of the oven. The rotisserie can be used with 6 small spits, as shown in the illustration. For bigger pieces of meat, remove the 6 small spits and the discs, and use only the big central spit.

The 6 small spits turn automatically during grilling. Make sure the rotisserie is positioned right by visually checking it rotates correctly for the first minute of operation.

The rotisserie set contains a handle, which can be screwed into the central spit for easier handling. Remove the handle before closing the oven door.

Note

Recommended temperature for grilling is 220 °C.

Preheating for three minutes is recommended.

EN

Convection + Bottom Heat ( ) Setting

Hot air and the bottom heating element combine to heat food. This is a useful setting for crisping and browning.



Baking tray or oven rack is often used on Level 3.

*Please ensure that glass baking dishes are suitable for 40 ~ 250 °C cooking temperatures.

Cooking Guide

Use temperatures and times in this table as guidelines for baking. We recommend to preheat the oven with Convection + Bottom Heat mode.

Food Item	Shelf Level	Temperature (°C)	Accessory	Time (h)
Fresh Pizza	3	180 - 200	Baking tray	0:15 - 0:25
Chilled Pre-baked Quiche / Pie	2	180 - 200	Oven rack	0:10 - 0:15
Frozen Self Rising Pizza	2	180 - 200	Baking tray	0:15 - 0:20
Frozen Pizza	3	200 - 220	Oven rack	0:10 - 0:15
Chilled Pizza	3	180 - 220	Baking tray	0:08 - 0:15
Frozen Puff Pastry with Fruit Filled	2	180 - 200	Baking tray	0:10 - 0:15

Note

Preheating is recommended.

Setting Cook Time

EN



1 Select the desired oven function and temperature. (See also section “Changing the oven function and temperature)

Note

If there is no further entry on the control panel for 5 seconds, start key will blink.



2 Press **COOK TIME**.



3 Turn **MULTI-FUNCTION SELECTOR** to set desired cook time.

1) After 5 seconds, setting cook time ends automatically and **START** blinks.

2) Press **COOK TIME** to end setting cook time.



4 Press **START** the oven will start promptly.

5 When the set time has elapsed, an audible signal sounds and the oven switches itself off.

Note

More / Less function. During cooking, you can adjust the pre-set cooking time with **MULTI-FUNCTION SELECTOR** for better cooking performance.

Setting End Time

EN



1 Select the desired oven function and temperature.

2 Press **END TIME**.
The current time will be shown blinking on the DISPLAY.

Example Current time is 13:00
The current time's digit "13:00" will blink.



3 Turn **MULTI-FUNCTION SELECTOR** to set desired hour and minute. (14:00).

Example Desired time is 14:00.



4 Press **END TIME** again.

Example Current time is 13:00.
Desired end time is 14:00.
Cooking time "1:00" is displayed.



5 Press **START** to start the oven.
The oven will start promptly.

Note

1) The cooking time will count down in the time display. When the set time has elapsed, an audible signal sounds and the oven switches itself off.
2) During cooking, you can adjust the preset cooking time with the **MULTI-FUNCTION SELECTOR** for better cooking performance.
3) During cooking, the inside temperature is displayed by pressing **TEMPERATURE** and **POWER LEVEL / ENTER** at the same time.

Cooking Time Reservation Function

EN

Example: Current time : 12:00
Cook time : 2:00 you wish to end cooking at 18:00



1 Select Oven Mode and desired function.

2 Select Cook Time and enter the desired cook time. (2:00)



3 Press **END TIME**.

► The Cook Time is added to the current time and “14:00” is displayed.

► Enter the desired End Time. (18:00)



4 Press **END TIME**.

► The oven automatically starts at the reserved time of 16.:00.

► The Cook Time is displayed at the start of cooking.

Note

- End Time is displayed when reservation is completed.
- Cook Time and End Time can be changed before the reserved time.

Using Speed Menu Mode

EN

Speed Menu Mode allows you to choose from twelve pre-programmed settings to conveniently cook, roast or bake your favourite foods. Cooking time and power level are automatically set. Simply select one of the twelve settings and set the weight to start cooking.

Setting Speed Menu Mode



1 Turn **MODE SELECTOR** to Speed Menu position.



2 Turn **MULTI-FUNCTION SELECTOR** to select desired Speed Menu setting. Refer to table on pages 26 - 27 for a description of the 12 Speed Menu settings.



3 Press the **POWER LEVEL/ ENTER** to change weight or:



4 Turn **MULTI-FUNCTION SELECTOR** to select desired weight.



5 Press **START**.

Note

- Some of the speed menus are continuous. Others require the food to be turned over. the oven will beep to prompt you.
- The oven temperature set during the operation of the speed menu is displayed.
- Temperatures and times cannot be changed during cooking.

EN

Guide to Auto Speed Menu Settings

The following table presents 12 Auto Programmes for Speed Cooking, Roasting and Baking. It contains quantities, standing times and appropriate recommendations. These auto programmes contain special cook modes, which have been developed for your convenience.

No	Food Item	Weight (kg)	Accessory	Shelf Level	Recommendation
1	Frozen Pizza	0.1 - 0.2 0.2 - 0.3 0.3 - 0.4 0.4 - 0.5	Grill insert with ceramic tray	4	Put frozen pizza in the middle of grill insert with ceramic tray.
2	Frozen Oven Chips	0.2 - 0.4 0.4 - 0.6 0.6 - 0.8	Baking tray	3	Distribute frozen oven chips on metal baking tray.
3	Frozen Croquettes	0.4 - 0.5 0.5 - 0.6 0.6 - 0.7 0.7 - 0.8	Grill insert with ceramic tray	4	Put frozen potato croquettes evenly on grill insert with ceramic tray.
4	Frozen Lasagne	0.3 - 0.4 0.5 - 0.6 0.7 - 0.8 0.9 - 1.0	Ceramic tray	3	Put frozen lasagne in a suitable glass pyrex or ceramic dish. After reheating let stand for 3 - 4 min.
5	Frozen Fish Gratin	0.3 - 0.4 0.5 - 0.6 0.7 - 0.8	Ceramic tray	3	Put frozen fish gratin in a suitable glass pyrex or ceramic dish. After cooking stand for 3 - 4 minutes.
6	Chicken Pieces	0.2 - 0.4 0.4 - 0.6 0.6 - 0.8 0.8 - 1.0	Grill insert with ceramic tray	4	Brush chilled chicken pieces with oil and spices. Put on grill insert with ceramic tray with the skin-side down. Turn over, as soon as the oven beeps. After cooking let stand for 2 minutes.
7	Whole Chicken	0.8 - 0.9 1.0 - 1.1 1.2 - 1.3 1.4 - 1.5	Grill insert with ceramic tray	3	Brush chilled chicken with oil and spices and put breast-side-down on the grill insert with ceramic tray. Turn over, as soon as the oven beeps. After cooking let stand for 5 minutes.
8	Beef Steaks	0.3 - 0.6 0.6 - 0.8	Grill insert with ceramic tray	4	Put beef steaks side by side in the middle of grill insert with ceramic tray.

No	Food Item	Weight (kg)	Accessory	Shelf Level	Recommendation
9	Roast Beef	0.7 - 0.8 0.9 - 1.0 1.1 - 1.2 1.3 -1.5	Grill insert with ceramic tray	3	Marinate roast beef and put on grill insert, set on ceramic tray with the fat side down. Turn over as soon as the oven beeps. After cooking wrap in aluminium foil and let stand for 5 - 10 minutes.
10	Baked Potatoes	0.2 - 0.4 0.4 - 0.6 0.6 - 0.8 0.8 - 1.0	Grill insert with ceramic tray	4	Wash and clean potatoes and pierce with a fork. Put potatoes (each 200 - 250g) side by side on grill insert with ceramic tray. After cooking let stand for 3 - 5 minutes.
11	Cake	0.5 - 0.6 0.7 - 0.8 0.9 - 1.0	Ceramic tray	3	Put dough into suitable sized round glass pyrex baking dish. This programme is suitable for batter such as marble cake, lemon cake and hazelnut cake.
12	Muffins	0.5 - 0.6 0.7 - 0.8	Oven rack	3	Put muffin dough in metal muffin dish, suitable for 12 muffins. Set dish on oven rack. 0.5 - 0.6 kg weight range is recommended for muffins of each 45 g, 0.7 - 0.8 kg weight range is recommended for medium sized muffins of each 65 g.

Important

Most of Speed Menu Mode settings use microwave energy to heat food. Therefore guidelines for cookware and other microwave safety precautions must be strictly observed when using this mode.

Using Speed Defrost Mode

EN

Setting Speed Defrost Mode

Choose from five pre - programmed microwave settings for defrosting. Defrosting time and power level are automatically set. Simply select the setting and weight to start defrosting.

Open the door. Place the frozen food in the centre of the ceramic tray. Position is level 1. Close the door.



1 Turn **MODE SELECTOR** to the **Speed Defrost** ( ) symbol.



2 Turn **MULTI-FUNCTION SELECTOR** to choose desired defrost item. Press **POWER LEVEL / ENTER** to set desired defrost item. (Refer to table on page 29 for a description of the 5 Speed Defrost settings.)



3 Select the food weight by turning the **MULTI-FUNCTION SELECTOR**.



4 Press **START** to start cooking.

When cooking has finished, the oven will beep and flash “End” four times. The oven will then beep once every minute for 3 minutes.

Result
- ◆ Defrosting begins.
- ◆ The oven beeps half way through defrosting to remind you to turn the food over.

Important

- Use only containers that are microwave - safe.
- You can also defrost food manually. To do so, select the microwave Cooking / Reheating function with a power level of 180 W. Refer to the section entitled “Cooking / Reheating” on page 37 for further details.

Using Speed Defrost Mode (Continued)

Guide to Auto Speed Defrost Settings

The following table presents the various Auto Defrost programmes, quantities, standing times and appropriate recommendations. These programmes use microwave energy only. Remove all packaging material before defrosting. Place meat, poultry and fish on the ceramic tray.

No	Food Item	Weight (kg)	Acces-sory	Shelf Level	Standing Time (min)	Instructions
1	Meat	0.2 - 2.0	Ceramic tray	1	20 - 90	Shield the edges with aluminium foil. Turn the meat over, when the oven beeps. This programme is suitable for beef, lamb, pork, steaks, chops, minced meat.
2	Poultry	0.2 - 2.0	Ceramic tray	1	20 - 90	Shield the leg and wing tips with aluminium foil. Turn the poultry over, when the oven beeps. This programme is suitable for whole chicken as well as for chicken portions.
3	Fish	0.2 - 2.0	Ceramic tray	1	20 - 60	Shield the tail of a whole fish with aluminium foil. Turn the fish over, when the oven beeps. This programme is suitable for whole fishes as well as for fish fillets.
4	Bread / Cake	0.1 - 1.0	Ceramic tray	1	10 - 30	Put bread on a piece of kitchen paper and turn over, as soon as the oven beeps. Place cake on ceramic tray and if possible, turn over, as soon as the oven beeps. (Oven keeps operating and is stopped, when you open the door.) This programme is suitable for all kinds of bread, sliced or whole, as well as for bread rolls and baguettes. Arrange bread rolls in a circle. This programme is suitable for all kinds of yeast cake, biscuit, cheese cake and puff pastry. It is not suitable for short / crust pastry, fruit and cream cakes as well as for cake with chocolate topping.
5	Fruit	0.1 - 1.0	Ceramic tray	1	5 - 15	Distribute frozen fruit evenly on ceramic tray. This programme is suitable for fruits like raspberries, mixed berries, and tropical fruits.

Important

The Speed Defrost Mode uses microwave energy to heat food.
Therefore guidelines for cookware and other microwave safety precautions must be strictly observed when using this mode.

How a Microwave Oven Works

EN

Microwaves are high - frequency electromagnetic waves; the energy released enables food to be cooked or reheated without changing either the form or the colour.

You can use your microwave to:

- ***Defrost***
- ***Cook***

Cooking Principle



1. The microwaves generated by the magnetron are distributed uniformly by using a stirrer distribution system. The food is thus cooked evenly.
2. The microwaves are absorbed by the food up to a depth of about 1 inch (2.5 cm). Cooking then continues as the heat is dissipated within the food.
3. Cooking times vary according to the container used and the properties of the food:
   - Quantity and density
   - Water content
   - Initial temperature (Refrigerated or not)

Important

As the centre of the food is cooked by heat dissipation, cooking continues even when you have taken the food out of the oven.

Standing times specified in recipes and in this booklet must therefore be respected to ensure
- Even cooking of the food right to the centre
- The same temperature throughout the food

Using Microwave Mode

EN

Microwaves are high frequency electromagnetic waves. In microwave cooking, microwave energy penetrates food, attracted and absorbed by its water, fat and sugar content. The microwaves cause the molecules in the food to move rapidly. The rapid movement of these molecules creates friction and the resulting heat cooks the food.

Setting Microwave Mode



1 Turn **MODE SELECTOR** to microwave position. Time and power level will appear on DISPLAY.



2 Turn **MULTI-FUNCTION SELECTOR** to set desired cooking time. When cooking time is set, **START** will blink. If you do not wish to change power level, press **START** to start cooking.



3 To change power level, press **POWER LEVEL / ENTER** and turn **MULTI-FUNCTION SELECTOR** to desired level. Refer to Cooking Guides (pages 31 to 40) for guidelines on appropriate cooking times and power levels.



4 Press **START** to start cooking.

EN

Guide to Microwave Power Levels

POWER LEVEL	PERCENTAGE (%)	OUTPUT POWER (W)	REMARK
HIGH	100	900	For heating up liquids.
HIGH LOW	83	750	For heating up and cooking food.
MEDIUM HIGH	67	600	For heating up and cooking food.
MEDIUM	50	450	For cooking meat and heating up delicate foods.
MEDIUM LOW	33	300	
DEFROST	20	180	For defrosting and continued cooking.
LOW	11	100	For defrosting delicate foods.

EN

Microwave Cookware Guide

Cookware used for Microwave Mode must allow microwaves to pass through and penetrate food. Metals such as stainless steel, aluminum and copper reflect microwaves. Therefore, do not use cookware made of metallic materials. Cookware marked microwave - safe is always safe for use. For additional information on appropriate cookware refer to the following guide and always use the ceramic tray on shelf Level 1 when using microwave mode.

COOKWARE	MICROWAVE-SAFE	COMMENTS
Aluminium Foil	✓ ✗	Can be used in small quantities to protect areas against overcooking. Arcing can occur if the foil is too close to the oven wall or if too much foil is used.
Crusting Plate	✓	Do not preheat for more than 8 minutes.
China and Earthenware	✓	Porcelain, pottery, glazed earthenware and bone china are usually suitable, unless decorated with a metal trim.
Disposable Polyester Cardboard Dishes	✓	Some frozen foods are packaged in these dishes.
Fast - Food Packaging • Polystyrene cups containers • Paper bags or newspaper • Recycled paper or metal trims	 ✓ ✗ ✗	 Can be used to warm food. Overheating may cause the polystyrene to melt. May catch fire. May cause arcing.
Glassware • Oven-to-table ware • Fine glassware • Glass jars	 ✓ ✓ ✓	 Can be used, unless decorated with a metal trim. Can be used to warm foods or liquids. Delicate glass may break or crack if heated suddenly. Must remove the lid. Suitable for warming only.
Metal • Dishes • Freezer bag twist ties	 ✗ ✗	 May cause arcing or fire.

Using Microwave Mode (Continued)

COOKWARE	MICROWAVE-SAFE	COMMENTS
Paper		
• Plates, cups, napkins and Kitchen paper	✓	For short cooking times and warming. Also to absorb excess moisture.
• Recycled paper	✗	May cause arcing.
Plastic		
• Containers	✓	Particularly if heat-resistant thermoplastic. Some other plastics may warp or discolour at high temperatures. Do not use Melamine plastic.
• Cling film	✓	Can be used to retain moisture. Should not touch the food. Take care when removing the film as hot steam will escape.
• Freezer bags	✓✗	Only if boilable or oven-proof. Should not be airtight. Prick with a fork, if necessary.
Wax or Grease-proof Paper	✓	Can be used to retain moisture and prevent spattering.

Note

"Arcing" is the microwave term for sparks in the oven.

✓ : Recommended
✓✗ : Use Caution
✗ : Unsafe

EN

Microwave Cooking Guide

GENERAL GUIDELINES

Food Suitable for Microwave Cooking
Many kinds of food are suitable for microwave cooking, including fresh or frozen vegetables, fruit, pasta, rice, grains, beans, fish, and meat. Sauces, custard, soups, steamed puddings, preserves, and chutneys can also be cooked in a microwave oven. Generally speaking, microwave cooking is ideal for any food that would normally be prepared on a hob.

Covering During Cooking
Food should be covered during cooking, as the evaporated water rises as steam and contributes to the cooking process. Food can be covered in different ways such as with a ceramic plate, plastic cover or microwave suitable cling film.

Standing Times
After cooking, it is important to let food stand for the recommended standing time to allow the temperature to even out within the food.

COOKING GUIDE FOR FROZEN VEGETABLES

Use a suitable glass Pyrex bowl with lid. Cook covered for the minimum time (See table). Continue cooking to get the result you prefer. Stir twice during cooking and once after cooking. Add salt, herbs or butter after cooking. Keep covered during standing time.

Food	Portion (g)	Power (W)	Time (Min)	Standing Time (Min)	Instructions
Spinach	150	600	5 - 6	2 - 3	Add 15 ml (1 tbsp) cold water.
Broccoli	300	600	8 - 9	2 - 3	Add 30 ml (2 tbsp) cold water.
Peas	300	600	7 - 8	2 - 3	Add 15 ml (1 tbsp) cold water.
Green Beans	300	600	7½ - 8½	2 - 3	Add 30 ml (2 tbsp) cold water.
Mixed Vegetables (Carrots / Peas / Corn)	300	600	7 - 8	2 - 3	Add 15 ml (1 tbsp) cold water.
Mixed Vegetables (Chinese Style)	300	600	7½ - 8½	2 - 3	Add 15 ml (1 tbsp) cold water.

EN

COOKING GUIDE FOR FRESH VEGETABLES

Use a suitable glass Pyrex bowl with lid. Add 30 - 45 ml cold water (2 - 3 tbsp) for every 250 g unless another water quantity is recommended (see table) Cook covered for the minimum time (see table) Continue cooking to get the result you prefer. Stir once during and after cooking. Add salt, herbs or butter after cooking. Cover during the 3 minute standing time.

Hint : Cut fresh vegetables into even sized pieces. The smaller they are cut the quicker they are cooked.

Note : All fresh vegetables should be cooked using full microwave power (900 W).

Food	Portion (g)	Time (Min.)	Standing Time (Min.)	Instructions
Broccoli	250 500	3 - 4 6 - 7	3	Prepare even sized florets. Arrange stems to the centre.
Brussels Sprouts	250	5 - 6	3	Add 60 - 75 ml (5 - 6 tbsp) water.
Carrots	250	4 - 5	3	Cut carrots into even sized slices.
Cauliflower	250 500	4 - 5 7 - 8	3	Prepare even sized florets. Cut big florets into halves. Arrange stems to the centre.
Courgettes	250	3 - 4	3	Courgettes into slices. Add 30 ml (2 tbsp) water or a knob of butter. Cook until just tender.
Egg Plants	250	3 - 4	3	Cut egg plants into small slices and sprinkle with 1 tablespoon lemon juice.
Leeks	250	3 - 4	3	Cut leeks into thick slices.
Mushrooms	125 250	1 - 2 2 - 3	3	Prepare small whole or sliced mushrooms. Do not add any water. Sprinkle with lemon juice. Spice with salt and pepper. Drain before serving.
Onions	250	4 - 5	3	Cut onions into slices or halves. Add only 15 ml (1 tbsp) water.
Pepper	250	4 - 5	3	Cut pepper into small slices.
Potatoes	250 500	4 - 5 7 - 8	3	Weigh the peeled potatoes and cut them into similar sized halves or quarters.
Turnip Cabbage	250	5 - 6	3	Cut turnip cabbage into small cubes.

EN

COOKING GUIDE FOR RICE AND PASTA

Rice Use a large glass Pyrex bowl with lid. (Note that rice doubles in volume during cooking.) Cook covered. After cooking time is over, stir before letting stand. Add salt or herbs and butter. Note that rice may not have absorbed all water after the cooking time is finished.

Pasta Use a large glass Pyrex bowl. Add boiling water, a pinch of salt and stir well. Cook uncovered. Stir occasionally during and after cooking. Cover during standing time and drain thoroughly afterwards.

Food	Portion (g)	Power (W)	Time (Min)	Standing Time (Min)	Instructions
White Rice (Parboiled)	250 375	900	15 - 16 17½ - 18½	5	Add 500 ml cold water. Add 750 ml cold water
Brown Rice (Parboiled)	250 375	900	20 - 21 22 - 23	5	Add 500 ml cold water. Add 750 ml cold water
Mixed Rice (Nice + Wild Rice)	250	900	16 - 17	5	Add 500 ml cold water.
Mixed Corn (Rice + Grain)	250	900	17 - 18	5	Add 400 ml cold water.
Pasta	250	900	10 - 11	5	Add 1000 ml hot water.

REHEATING

Your microwave oven will reheat food in a fraction of the time a conventional oven takes.

Arranging and Covering
Avoid reheating large items such as joints of meat since they tend to overcook and dry out before the centre is piping hot. You will have more success reheating smaller pieces. Keeping food covered while heating will also help prevent drying.

Power Levels
Different power levels can be used for reheating foods.
In general, for large quantities of delicate food or foods that heat up quickly, such as mince pies, it is better to use a lower power level.

Stirring
Stir well or turn food over during reheating for best results. When possible, stir again before serving. Stirring is especially important when heating liquids.

Heating and Standing Times
When reheating food for the first time, it is helpful to make a note of the time taken for future reference. Avoid overheating. If uncertain, it is preferable to underestimate cooking time. Then extra heating time can be added, if necessary. Always make sure that reheated food is piping hot throughout. Allow food to stand for a short time after reheating to let the temperature even out. The recommended standing time after reheating is 2 - 4 minutes.

EN

REHEATING LIQUIDS

Take special care when heating liquids. To prevent eruptive boiling and possible scalding, place a spoon or glass stick in the beverage. Stir during heating and always stir after heating. Allow a standing time of at least 20 seconds after the oven has been switched off to allow the temperature to even out.

REHEATING BABY FOOD

Baby Food

Extra caution should also be exercised when reheating baby foods. Put food into a deep ceramic plate. Cover with plastic lid. Stir well after reheating. Let stand for 2 - 3 minutes before serving. Stir again and check temperature. Recommended serving temperature is between 30 - 40 °C.

Baby Milk

Pour milk into a sterilised glass bottle. Reheat uncovered. Never heat a baby's bottle with the nipple on, as the bottle may explode if overheated. Shake well before standing time and again before serving. Always carefully check the temperature of baby milk or food before serving. Recommended serving temperature is 37°C.

DEFROSTING

Microwaves are an excellent way of defrosting frozen food. Microwaves gently defrost frozen food in a short period of time. This can be a great advantage, if unexpected guests suddenly show up.

Frozen poultry must be thoroughly thawed before cooking. Remove any metal ties and take it out of any wrapping to allow thawed liquid to drain away.

Put the frozen food on a dish without a cover. Turn over half way, drain off any liquid and remove any giblets as soon as possible.
Check the food occasionally to make sure that it does not feel warm.
If smaller and thinner parts of the frozen food start to warm up, they can be shield by wrapping very small strips of aluminium foil around them during defrosting.

Should poultry start to warm up on the outer surface, press **STOP / CANCEL** and allow it to stand for 20 minutes before continuing.
Leave the fish, meat and poultry to stand in order to complete defrosting.
The standing time for complete defrosting will vary depending on the quantity defrosted.
Please refer to the table on the next page.

Hint Flat food is defrosted better than thicker items, and smaller quantities need less time than bigger ones. Remember this hint while freezing and defrosting food.

For defrosting of frozen food with a temperature of about - 18 to - 20°C, use the following table as a guide.

Frozen foods should be defrosted using defrosting power level (180 W).

Using Microwave Mode (Continued)

Food	Portion	Time (Min)	Standing Time (Min)	Instructions
Meat				
Minced Beef	250 g 500 g	6 - 7 10 - 12	15 - 30	Place the meat on the ceramic plate. Shield thinner edges with aluminium foil.
Pork Steaks	250 g	7 - 8		Turn over after half of defrosting time.
Poultry				
Chicken Pieces	500 g (2 pcs)	12 - 14	15 - 60	First, put chicken pieces skin - side down, whole chicken breast - side - down first on ceramic plate. Shield the thinner parts like wings and ends with aluminium foil. Turn over after half of defrosting time
Whole Chicken	1200 g	28 - 32		
Fish				
Fish Fillets	200 g	6 - 7	10 - 25	Put frozen fish in the middle of ceramic plate. Arrange the thinner parts under the thicker parts. Shield narrow ends of fillets and tail of whole fish With aluminium foil. Turn over after half of defrosting time!
Whole Fish	400 g	11 - 13		
Fruit				
Berries	300 g	6 - 7	5 - 10	Spread fruit on a flat, round glass dish with a large diameter.
Bread				
Bread Rolls (Each ca. 50 g)	2 pcs 4 pcs	1 - 1½ 2½ - 3	5 - 20	Arrange rolls in a circle or bread horizontally on kitchen paper on the ceramic plate. Turn over after half of defrosting time.
Toast / Sandwich	250 g 500 g	4 - 4½ 7 - 9		

EN

QUICK & EASY

Melting Butter
Put 50 g of butter into a small deep glass dish. Cover with plastic lid.
Heat for 30 - 40 seconds using 900 W.

Melting Chocolate
Put 100 g of chocolate into a small deep glass dish.
Heat for 3 - 5 minutes using 450 W.
Stir once or twice during melting.

Melting Crystallized Honey
Put 20 g crystallized honey into a small deep glass dish.
Heat for 20 - 30 seconds using 300 W.

Melting Gelatine
Place dry gelatine sheets (10 g) in cold water for 5 minutes.
Put drained gelatine into a small glass Pyrex bowl.
Heat for 1 minute using 300 W.
Stir after melting.

Cooking Glaze or Icing
Mix instant glaze (approximately 14 g) with 40 g of sugar and 250 ml of cold water.
Cook uncovered in a glass Pyrex bowl using 900W until glaze / icing is transparent (about 3½ to 4½ minutes). Stir twice during cooking.

Cooking Jam
Put 600 g of fruits such as mixed berries in a suitably sized glass Pyrex bowl.
Add 300 g of preserving sugar and stir well.
Cook covered for 10 - 12 minutes using 900W.
Stir several times during cooking.
Empty directly into small jam glasses with twist - off lids.
Let stand with lid on for 5 minutes.

Cooking Pudding
Mix pudding powder with sugar and milk (500 ml) by following the manufacturers instructions and stir well. Use a suitable sized glass Pyrex bowl with lid.
Cook covered for 6½ to 7½ minutes using 900 W.
Stir several times during cooking.

Browning Almond Slices
Spread 30 g sliced almonds evenly on a medium-sized ceramic plate.
Heat for 3½ to 4½ minutes using 600 W, stirring several times.
Let stand for 2 to 3 minutes in the oven.

Switching Off the Beeper

EN

The oven beeps at the end of cooking and "End" blinks 4 times on the display.



1 To switch beeper off, press **STOP / CANCEL (⊘)** and **START (◇)** at the same time and hold for one second.



2 To switch beeper back on, press **STOP / CANCEL (⊘)** and **START (◇)** again at the same time and hold for one second.

Child Safety Lock

EN

The oven's Child Safety Lock allows you to lock the control panel to protect the oven against unintended use.

To Lock Oven



1 Press **STEAM CLEAN** and **CLOCK** at the same time and hold for 3 seconds.

2 Lock symbol appears on DISPLAY indicating all functions locked.

To Unlock Oven



1 Press **STEAM CLEAN** and **CLOCK** at the same time and hold for 3 seconds.

2 Lock symbol disappears indicating functions unlocked.

Using the Steam Clean Feature

EN

The Steam Clean feature allows you to sanitize your oven in just 15 minutes.





1 Turn **MODE SELECTOR** to “Off” position.

► Pour about 100 ml water onto the floor of the empty oven.

2 Press **STEAM CLEAN**. The oven will start automatically.

► After 15 minutes, the oven will stop automatically. Wipe it out with a dry cloth.



Important

- Use this feature only when oven has cooled completely to room temperature.
- DO NOT use distilled water.

Cleaning Your Microwave Oven

Clean your oven regularly to prevent grease and food particles from building up, especially on inside and outside surfaces, door and door seals.

1. Clean outside surfaces with a soft cloth and warm soapy water. Rinse and dry.
2. Remove any splashes or stains on inside surfaces with a soapy cloth. Rinse and dry.
3. To loosen hardened food particles and remove smells, place a cup of diluted lemon juice on the floor of the empty oven and heat for ten minutes at maximum power.
4. Wash the inside.

Important

- Take special care NOT to spill water in the vents.
- NEVER use abrasive products or chemical solvents.
- ALWAYS ensure that door seals are clean to prevent particles from building up so that the door can close properly.

Storing and Repairing Your Microwave Oven

Repairs should only be made by a qualified service technician.
If oven requires servicing, unplug the oven and contact the nearest Samsung Customer Service Center.

When calling, please have the following information ready:

- ***The model number and serial number (Can be found at rear of the oven.)***
- ***Warranty details***
- ***Clear description of the problem***

If oven must be temporarily stored, choose a clean dry place as dust and dampness can cause damage.

Troubleshooting

EN

If you have problems with your oven, try the solutions suggested below. They may save you the time and inconvenience of an unnecessary service call.

- Food remains uncooked.
  - Ensure timer has been set correctly and START button pressed.
  - Firmly close door.
  - Make sure you have not blown a fuse or triggered a circuit breaker.

- Food is either overcooked or undercooked.
  - Make sure appropriate cook time was used.
  - Make sure appropriate power level was used.

- Sparking and cracking (arcing) occur inside the oven.
  - Make sure you are using proper cookware without metal trimmings.
  - Make sure no forks or other metal utensils have been left inside the oven.
  - If using aluminum foil, make sure it is not too close to inside walls.

- The oven causes interference with radios or televisions.
  - Slight interference on televisions or radios may occur when the oven is operating. To minimize this effect, try to install oven away from televisions, radios and aerials.

- Electronic interference causes DISPLAY to be reset.
  - Disconnect the power plug and reconnect it. Reset the time.

- Condensation appears inside the oven.
  - This is a normal occurrence. Simply wipe away after cooking.

- The fan continues to operate after the oven has been turned off.
  - This is a normal occurrence. Cooling fan may continue to operate for up to three minutes after oven has been turned off.

- Air flow is detected around the door and outer casing.
  - This is a normal occurrence.

- Light reflection around the door and outer casing.
  - This is a normal occurrence.

- Steam escapes from around the door or vents.
  - This is a normal occurrence.

- A clicking sound occurs while the oven is operating, especially in defrosting mode.
  - This is a normal occurrence.

Error Codes

EN

Error Code	General Functions
	TEMP SENSOR OPEN In case the value of the temperature sensor is more than 250 °C during operation / cancellation.
	TEMP SENSOR SHORT In case the value of the temperature sensor is less than 5 °C during operation / cancellation.
	OVER 210 °C DURING OPERATION OF MWO In case the temperature rises over 210 °C during operation of MWO (FIRE sensed)
	DAMPER S/W In case it fails to sense the DAMPER to open or close for 2 minutes.

Technical Specifications

EN

" Samsung strives to improve its products at all times. Both the design specifications and these user instructions are thus subject to change without notice. "

Model	**CQ4260**
Power Source	230 V ~ 50 Hz
Power Consumption Maximum power Microwave Top Grill Bottom Heater Dual Convection	 3150 W 1650 W 2800 W 1000 W 3000 W
Output Power	100 W / 900 W (IEC - 705)
Operating Frequency	2450 MHz
Magnetron	OM75P (20)
Cooling Method	Cooling fan motor
Dimensions (W x H x D) Outside Oven cavity	 595 x 460 x 520 mm 429 x 229 x 430 mm
Volume	42 liter
Weight Net Shipping	 36.5 kg approx 44.0 kg approx

ELECTRONICS

Code No.: DG68-00015E